

DISHY HOME COMPACT INSTALLATION GUIDE

1. Plug in water inlet (1) and drainage pipe (2) into machine.



DISHY HOME COMPACT INSTALLATION GUIDE

2. Water Supply Connection


Option 1: connecting to Sink Tap

Use a 2 Way Faucet Adapter to split the water supply from Sink Tap.



2 Way Faucet
Adapter

Connect
dishwasher water
hose to Sink Tap
using the adapter




DISHY HOME COMPACT INSTALLATION GUIDE

2. Water Supply Connection

Option 2: connecting to Washing Machine water point

Use a splitter to split the water supply
from Washing Machine water point



DISHY HOME COMPACT INSTALLATION GUIDE

3. Hang the drainage pipe into the sink or attach the other end of drainage pipe into the drainage point found near washing machine area



Hang the drainage pipe into sink



Connect to washing machine drainage

DISHY HOME COMPACT INSTALLATION GUIDE

4. Plug the electrical plug into power socket and switch on.



DISHY HOME COMPACT INSTALLATION GUIDE

5. Press the power button on the dishwasher and the machine is ready to function.

